




FIGURE 4. DISSASSEMBLING YOUR AMPLIFIER.




TOP




BOTTOM



LEFT SIDE




RIGHT SIDE



FRONT

NOTE
SCREWS 19 AND 20
ARE LOCATED ON THE
BOTTOM OF THIS
SURFACE.



REAR